

Playback

INFORMATION ON PLAYBACK	47
Structure of Disc Contents	47
BASIC PLAYBACK	48
Direct Playback	48
Playback from the Title List	49
Playing Back an Audio CD and a CD-RW/R with MP3/JPEG Files	50
Using the Title/Disc Menu	51
Pause	51
SPECIAL PLAYBACK	52
Resume Playback	52
Fast Forward / Fast Reverse Playback	52
Skipping TV Commercials During Playback	52
Rapid Playback	53
Step by Step Playback	53
Slow Forward / Slow Reverse Playback	53
Zoom	54
Marker Setting	54
Chasing Playback during Recording	55
Simultaneous Playback and Recording	56
SEARCH	57
Title/Chapter Search	57
Track Search	57
Time Search	58
REPEAT/RANDOM/PROGRAM PLAYBACK/ SLIDE SHOW	59
Repeat Playback	59
Random Playback	59
Program Playback	60
Slide Show	60
SELECTING THE FORMAT OF AUDIO AND VIDEO ..	61
Switching Subtitles	61
Switching Audio Soundtrack	61
Switching Virtual Surround System	62
Switching Camera Angles	62
Reducing Block Noise	62
Adjusting Black Level	63

Editing

INFORMATION ON DISC EDITING	64
Guide to a Title List	64
Editing Discs	64
DELETING TITLES	65
CREATING/DELETING PLAYLIST	67
Adding Titles to a Playlist	67
Erasing All Playlist	68
EDITING DISCS	69
Putting Names on Titles	69
Setting Chapter Marks	71
Hiding Chapters	72
Deleting a Part of a Title	73
Dividing a Title	75
Combining Titles	76
Setting or Releasing the Title Protection	77
Setting or Clearing All Chapter Marks at Once	78

Function Setup

LIST OF THE DEFAULT SETTINGS	79
GENERAL SETTING	81
Playback	81
Display	85
Video	88
HDMI	89
Reset All	91

Others

TROUBLESHOOTING	92
Frequently Asked Questions	95
LANGUAGE CODE	96
GLOSSARY	97
SPECIFICATIONS	98
LIMITED WARRANTY	99